





# INSTRUCTIONS KOVM




013R9175


013R9175




Varmtvandssystem eller koldtvandssystem  
Hot water system or cold water system  
Warmwassersystem oder Kaltwassersystem  
Installation d'eau chaude ou installation d'eau froide  
Varmvattensystem eller kallvattensystem





Koldt- og varmtvandssystem  
Cold and hot water system  
Kalt- und Warmwassersystem  
Installation d'eau froide et chaude  
Kall- och varmvattensystem

DANFOSS  
A13-2039.10

Varmtvandssystem  
Hot water system  
Warmwassersystem  
Installation d'eau chaude  
Varmvattensystem

DANFOSS  
A13-2040.10

Varmtvandsprioritering  
Hot water priority  
Warmwasservorrangsschaltung  
Priorité eau chaude sanitaire  
Varmvattenprioritering

DANFOSS  
A13U65.12DANFOSS  
A13U65.13